MX-200 Quick Key Map

Use the map below to find the instrument you wish to use and then send the appropriate Variation Select (MSB) and Program Change message for that instrument.

To send a program change from a Rodgers Classic Organ™, hold [SET] and press the MIDI piston you wish to program. As the piston flashes, press the key or pedal which corresponds to the voice you wish to select.

To use the MX-200 Quick Key Access with a Rodgers organ, the organ's MIDI coupler must also be set using the organ's Alpha Dial and Select Knob:

- For Rodgers Trillium organs: set MSB to 65–69 as shown on the map, and set LSB to 0.
- For Rodgers non-Trillium organs: set VAR to 65–69 as shown on the map.

CHOIR (3 Manual) / GREAT (2 Manual)

Capital Tone (MSB: 65)	PC	Variation 1 (MSB: 66)	Variation 2 (MSB: 67)	Variation 3 (MSB: 68)	Variation 4 (MSB: 69)
Pop Piano MX	1	Warm pF Mix			
Grand MX	2	Sparkle Piano	Honky Tonk MX		
Y2K Concerto	3	Piano + Strings	Piano + Soft Pad		
Fat Rhodes	4	Stage 73	Hit Rhodes		
Rholitzer	5	Smooth Rhodes	Mr.Mellow		
Stacc.Heaven	6	Morning Lite	Air Pad	Glistening	Phazweep
Stereo Harpsichord	7	Harpsichord Front	Harpsichord Back		
Harpsichord F/B/B4	8	Harpsichord F4/B			
Soft Celesta	9	Celestabox			
MX Glocken	10	Holiday Cheer	2020 Bell		
Music Bells	11	2.2 Bell Pad			
Warm Vibes	12	True Vibe	Ambience Vibe		
Dyna Marimba	13				
MX Xylophone	14				
Tubular Bells	15	Belfry Chime			
Handbell	16	Church Bell	Chime Bells		
Soft Perky	17	Soft B	Rocker Spin		
Ballad B	18	Perky B	Gospel Spin		
Surf's Up!	19	D-50 Organ	Full Stops		
MX Church Organ 1	20	MX Church Organ 2	MX Church Organ 3		
Church Harmony	21				
Cathedral	22	Wedding Mass			
Harmo Blues	23				
MX Accordion	24				
Soft Nylon	25	Nylon Guitar	Nice Guitar	Guitar & Pad	Desert Crystal
Steel Away	26	Thick Steel			
Jazz Guitar Hall	27				
Chamber Strings	28	Baroque 1			
Chamber Quartet	29	Full Chamber Strings			
Lead 4x Violins	30	Expressimo			
Octave Strings 2	31	Orchestral Strings			
Contrabass Section	32	Octave Strings 1	Slow Octave Strings		
MX Acoustic Bass	33				
Nylon Bass	34				
Pop Bass	35	Tap Bass			
Basic Fretless	36	MX Fretless			
Timpani Roll	37				
Harmonic Strings	38	Soft Symphony			
Full Orchestra	39	My Orchestra			
Brassy Symphony	40				
Warm Violin	41				
Slow Violin/Cello	42	Baroque 2			
Real Cello	43	Warm Cello			
Violin/Cello 1	44	Violin/Cello 2			
Full Tremolo	45				
Orchestral Pizzicato	46	Bass Pizzicato	Full Pizzicato mp		
Harp	47				
MX Timpani 2	48	MX Timpani 1	Orchestral Percussion Set		
Strings Ensemble	49	Marcato			
MX Strings	50	Ultra Smooth			
Lush Strings 2	51	Fat Strings			
Octave Strings 1	52	Film Octaves	Wide Strings		
Real Choir	53	Stereo Choir	Spaced Voxx		
Boys Choir Ooh	54	Boys Choir			
Voyager Brass	55	Slow Dark Brass			
Valve Job	56	Ceremonial			
MX Trumpet	57	Mellow Horn			
Mild Trombone	58	Trombone			
MX Tuba	59				
Cup Mute	60	Harmon Mute			
French Horn Section	61	Soft Horns	Bright Horn		

LSB: 0

GREAT (3 Manual) / SWELL (2 Manual)

Capital Tone (MSB: 65)	PC	Variation 1 (MSB: 66)	Variation 2 (MSB: 67)	Variation 3 (MSB: 68)
Fanfare	62	New R&R Brass		
Orchestral Brass	63			
Massed Horns	64	Soaring Horns		
Soprano Sax mf	65			
Alto Sax	66	Solo Alto Sax		
MX DynoTenor	67	Swingin' Bari	Breathy Sax	
Full Saxz	68	Sax Choir		
Oboe Vibrato	69	Oboe mf		
English Horn	70	Swell Ensemble		
Bassoon/English Horn	71			
MX Clarinet	72	Clarinet mp		
Bass Clarinet	73			
Tender Flute	74	Flute	Fifes	
Soprano Recorder	75	MX Ocarina		
Wind Wood	76	Wood Symphony		
Chamber Woods	77	Wind Multi		
Pan Pipes	78	Lochscapes	The Andes	
32' Contra Violone	79			
32' Untersatz	80			
32' Bazuin	81			
32' Posaune	82			
16' Posaune	83			
32' Contre Geigen	84			
16' Montre	85			
16' Pommer	86			
10-2/3' Gross Quint	87	21-1/3' Grave Diapente	5-1/3' Gross Quint	3-1/5' Gross Terz
8' First Diapason	88	8' Voce Umana II		
8' Second Diapason	89	8' Second Diapason (w/T)	8' Voce Umana II	Principal Chorus 8', 4', 2'
8' Harmonic Flute	90	8' Harmonic Flute (w/T)		
8' Quintadena	91	8' Quintadena (w/T)	16' Quintadena	
4' Major Flute	92	4' Major Flute (w/T)		
1' Sifflute	93	8/9' None		
IV Fourniture	94	IV Grave Mixture	IV Echo Mixture	
IV Scharf	95	II Jeu de Clochette		
II Sesquialtera	96	II Sesquialtera (w/T)		
IV Cornet 4'	97	IV Cornet 4' (w/T)		
16' Cello Celeste II	98			
16' Erzahler Celeste II	99			
16' Viols Chorus II	100			
8' Cello Celeste II	101			
8' Muted Viols II	102			
8' Viols Chorus IV	103	4' Viols Chorus II		
4' Violina Celeste II	104			
4' Erzahler Celeste II	105			
4' Flute Celeste II	106			
8' French Horn	107	8' French Horn (w/T)		
8' Cor d'Amour	108	8' Cor d'Amour (w/T)		
8' English Horn	109	8' English Horn (w/T)		
8' Vox Humana	110	8' Vox Humana (w/T)		
16' Royal Trumpet	111			
8' Royal Trumpet	112	4' Royal Trumpet	Royal Trumpets 16', 8', 4'	
8' Royal Tuba	113			
16' Tibia Clausa	114			
8' Tibia Clausa	115			
Tibias 8', 4'	116	Tibias 8', 4', 2'	Tibias 16', 8', 4', 2'	
4' Tibia Piccolo	117			
2-2/3' Tibia Twelfth	118	5-1/3' Tibia Fifth	1-3/5' Tibia Tierce	
2' Tibia Piccolo	119	1' Tibia Fife		
8' Vox Humana	120			
8' Kinura	121	8' Kinura (w/T)	2' Zink	
16' Posthorn	122	8' Posthorn		

* *w/T = with Trem*

LSB: 0

SWELL (3 Manual) / PEDAL (2 Manual)

Capital Tone (MSB: 65)	PC
Concert Bass Drum	123
Snare Roll	124
Orchestral Snare	125
Crash Cymbal	126
Ride Cymbal	127
Triangle	128
⋮	